

INSTRUCTIONS FOR WATERPROOF BINOCULARS

These waterproof binoculars are designed for all-weather activities.

They are waterproof, fog-proof, and anti-snow as well.

A. HOW TO ADJUST DISTANCE BETWEEN YOUR EYES


The distance between the eyes, called "interpupillary distance", varies from person to person. To achieve perfect alignment of lens to eyes, follow these simple steps.

1. Hold your binocular in the normal viewing position.
2. Grasp each barrel firmly. Move the barrels closer together or further apart until you see a single circular field of view. Always re-set your binocular to this position.

B. FOCUS SYSTEM

Unlike standard binoculars, your free focus binocular has no focusing mechanism. Your binocular is permanently in focus at all distances from a minimum focus point to infinity. Once you have adjusted for distance between your eyes, you are ready to enjoy the view.

C. ROLL DOWN EYECUPS



If you wear sun/eyeglasses, roll down the eyecups. This will bring your eyes closer to the lens thus providing improved field of view

D. FLOATING STRAP

1. The strap is specially designed to keep the binocular afloat and prevent the binocular from sinking in the water.
2. Before water sports activities, make sure the floatation strap is well equipped to the binocular.

E. INSTRUCTIONS FOR CARE

1. Always store your binocular in its case when not in use.
2. When wiping the lenses, use a soft lintless cloth.
3. To remove any remaining dirt or smudge, add one two drops of isopropyl alcohol to the cloth.
4. Store your binocular in a moisture-free area.

VERY IMPORANT

Never attempt to clean your binocular internally or try to take it apart.

CAUTION

Viewing the sun can cause permanent eye damage. Do not view the sun With this product or even with the naked eye.